



StarBart™



A way to fill the StarBart™ water ballast test dummy after you have set the legs of the dummy in a sitting or standing position.

StarBart filling steps



Bring the empty dummy up to ride



Turn on side to fill calves, which can be done from one side so you don't need to flip it over.

After the calves are full, turn the dummy over so it is face down. Fill each hip, then put dummy in the ride seat.



Fill torso/head portion of the dummy while it is in the ride seat. Be sure to turn all of the caps tightly. It is recommended that you twist these closed all the way by using pliers or wrench, especially at the waist so that it does not rub against the lap bar.

